




## SPARE PARTS LIST



## SPARE PARTS LIST



ITEM	DESCRIPTION	QTY	PART
1	Valve Chamber	1	TA-1255266
2	Valve Cover	3	TA-A5003
3	Valve Seat	6	TA-1225327
4	Valve Ball	6	TA-1187738
5	Packing Cup	3	TA-8495
6	Packing Washer	3	TA-1207289
7	Plunger Nut	3	TA-A5016
8	Packing - Standard	3	TA-A3434N
9	Nut	1	TA-8309
10	Ceramic Porcelain Cyl.	3	TA-A5034M
11	Cylinder Head	3	TA-A5002
12	Gasket Cylinder (Fibre)	3	TA-1280024
13	Gasket Cyl. Head(Fibre)	3	TA-1280025
14	Gasket Valve Cover(Fibre)	3	TA-1280026
15	Crosshead & Rod	3	TA-1250876
16	Clamp Cylinder Head	3	TA-1271415
17	Clamp Valve Cover	3	TA-1271716
18	Bearing Cap	1	TA-A5005
19	Pin	3	TA-A5006
20	Stud Cylinder	2	TA-A5009
21	Cylinder Cover Stud	6	TA-A5011
22	Valve Clamp Stud	6	TA-A5012
23	Bearing Housing	2	TA-1279064
24	Gasket	2	TA-A5026
25	Gasket	2	TA-A5025
26	Oil Cap	1	TA-A5054
27	Packing Washer	3	TA-1283602
28	Pump Case	1	TA-5260537
29	Gasket - Cover	1	TA-1279065
30	Cover ASM	1	TA-1279063

ITEM	DESCRIPTION	QTY	PART
31	Packing Nut	3	TA-1283600
32	Sleeve	3	TA-1283601
33	Connecting Rod	3	TA-18710
34	Bearing Eccentric	6	TA-P510831
35	Eccentric Gear ASM	1	TA-1279071
36	Pinion Shaft	1	TA-1265098
37	Plunger Rod Seal	6	TA-1283603
38	Shim	5	TA-1252594
39	Bearing Cap	1	TA-1225769
40	Cover Plate ASM	1	TA-1214260
41	Lube Fitting	3	TA-11100759
42	Set Screw	3	TA-1103470
43	Ball Bearing	2	TA-1104444
44	Seal Holder	3	TA-1281655
45	Seal	14	TA-1106910
46	Seal	12	TA-1100068
47	Seal	2	TA-1106980
48	Plug	2	TA-1187048
49	Hex Nut	14	TA-1121511
50	Lock Washer	3	TA-1100243
51	O-ring	3	TA-1101176
52	Cone Bearing	2	TA-1101242
53	Cup Bearing	2	TA-1177287
54	Bushing, Connecting Rod	3	TA-A5046
55	Bolt, Connecting Rod	6	TA-18743
56	Plug	1	TA-1105077
57	Plug	2	TA-1105105
58	Petcock	1	TA-1187039
59	Key	1	TA-1187577